

www.smipumps.co.za

# Super Premium Wrap







### FIBREGLASS WATER-ACTIVATED PIPE LEAK SEALING SOLUTION KIT

Super Premium Wrap, when used with appropriate primary sealant, enables you to repair and reinforce virtually any diameter pipe in just a few minutes. Super Wrap does not only restore a pipe to its original pressure rating but can make the repair area stronger than the original area, reducing downtime, saving in parts and labour. Super Wrap is excellent on copper, steal, Stainless Steel, PVC, Clay, concreter rubber and more Super Premium wrap is nontoxic, noncombustible, and odorless.

#### **Kit Contents**

- Step-by-Step Instructions
- Protective gloves
- Butyl Patch

#### **Benefits**

- Ready to use
- Effective, time-saving
- No mixing and no mess
- Sets rock hard in minutes

### **Typical Applications**

- Impact protection
- Emergency repair
- Cracked or corroded pipes
- Irregular pipe fittings
- Force mains and gravity lines
- Underwater repair
- Joint and tee repair

### **Properties**

Service Temp: -46 to 150°C (-50 to 250°F) Application Temp: 0 to 65°C (32 to 150°F) Pressure Once Cured Max 400 psi (28 bar) Working Time: 5 Minutes at 24°C (75°F) Set Time: 28 Minutes at 21°C (70°F) Application: Safe to use for potable water



Non-toxic

Strength: 25 BAR

Cures in 30 min at 21°C



Acid resistant

No tools required

Streng 25 B

## Our Products



### FIBREGLASS WATER-ACTIVATED PIPE LEAK SEALING SOLUTION KIT

### **READ ALL INSTRUCTIONS BEFORE OPENING PACKAGE!**

- 1. Depressurise pipe. Roughen pip surface using a wire brush to remove excess rust, dirt or loose scale. Remove any oils, greases, soaps or foreign materials from pipe surface using a solvent wipe.
- 2. Fill defect with putty, such as Premium Steel or apply Butyl Strip.
- 3. Water is needed to activate the Premium Wrap. Put on supplied gloves, open foil pouch and submerge the roll of PW in water for approximately 10 seconds.
- A minimum of 8 layers of PW is required and shall be applied in a clockwise direction from the right to left (R-T-L) or left to right (L-T-R) in a spirally wrapped manner around the pipe using 50% overlap.
- 5. At the end of the first wrap (R-T-L), reverse the direction of the wrap and continue to apply the PW (L-T-R) until you've achieved the specified number of layers. NOTE:
- 6. To achieve an 8 layer application, apply 4 passes using 50% overlap.

### Procedures to be taken in handling and storage

For ideal shelf life store Premium Wrap (PW) in a cool, shaded area at 23°C (72°F). Do not expose to temperature above 44 °C (110°F) or below 5°C (40°F). Care must be taken when handling Premium Wrap hermetically sealed foil pouch to prevent puncturing or scuffing, if the protective foil pouch is punctured, the Premium Wrap will be exposed to atmospheric moisture which will cause it to cure with the foil pouch.

### Precautions

The resin used in Premium Wrap will adhere to skin and clothing and may cause skin irritation. Protective gloves should be worn while handling. Care should be exercised to avoid contact with unprotected areas of skin and eyes. Swabbing lightly with alcohol or acetone will help remove resin from skin (prior to set). If eyes are exposed to the resin, flush eyes with water for 15 minutes and then contact physician. STORE IN A COOL, SHADED AND DRY AREA.